

# THUREN FABRICATION REAR TRACKBAR

**These instructions are applicable to the following Trucks:**

- 2009 - 2024 Ram 1500

Applicable Part Numbers:

2009 - 2024 TF-RAM1500-0924-RRTB



## 1. Pre-Install

- Park your vehicle on level ground and set the parking brake.
- No need to support the vehicle with jacks during this install.

## 2. Installation

- Remove OEM trackbar.
  - Remove hardware and rear OEM trackbar
- When installing the Rear Trackbar, align the trackbar so the "Thuren" sticker is facing the rear of the truck and positioned on the drivers side.

## 3. Install rear trackbar

### **WARNING**

Sometimes, the axle shifts after removal of OEM trackbar. Use the below notes to get Thuren Rear Trackbar aligned for install.

- If the mount holes are slightly off you can use the aid of a brass drift or similar item to move the trackbar into place.
- If the trackbar is a good distance away from the bolt hole, the aide of a ratchet strap from the frame to the axle will help. Tighten ratchet strap until the hole align, if possible use the help from a friend to install the bolts.
- Install factory hardware and torque 14mm bolt to **120 Ft / Lbs**



**THUREN**  
SUSPENSION TECHNOLOGY  
BEND · OREGON