

# THUREN FABRICATION HEIGHT SHIM KIT (HSK)

## These instructions are applicable to the following Trucks:

- 2014 2023 Ram 2500
- 2014 2023 Power Wagon Applicable Part Numbers: (TF-2500RCSPCR-KIT)

### - NOTE -

This kit will require removal of the rear coils for install. View our instructions for Rear Coil removal in our Tech Data section at www.thurenfabrication.com

#### 1. Installation

- Determine how many spacers you want to install. 1 = 5/8" lift, 2 = 1" lift, or 3 = 1-3/8" lift.
- Once the Rear Coils are removed, the Coil Spacer will bolt onto the Axle Seat where the Coil Previously sat.
- The supplied Black Top Plate will go on top of the Aluminum Spacer Plates and replicate the OEM mounting surface for your coil.
- Torque Hardware to 25 Ft/Lbs

#### - WARNING -

The minimum height option is one Spacer Plate and the Black Top Plate. Use the shorter bolts if you choose this option. Maximum Height is 3 Spacer Plates and Black Top Plate.

#### - IMPORTANT <del>-</del>

Must install and re-use, the factory lower rubber coil spring centering seat, on top of our Black spacer top plate.

