



THUREN FABRICATION PARKING BRAKE BRACKET

These instructions are applicable to the following Trucks:

- 2014-2018 2500/Power Wagon (Large Bracket)
- 2014-2023 2500/Power Wagon (Small Bracket)

Available Part Numbers:

- (TF-EBCBLRG-14U) Large Parking Brake Cable Bracket (*image 1*)
- (TF-EBCBSMALL-14U) Small Parking Brake Cable Bracket (*image 2*)



Image 1



Image 2

1. Large Parking Brake Bracket (*image 1*)

- Remove parking brake cable bracket from drivers side rear frame rail. Retain OEM Hardware.
- Install Large Thuren Parking Brake Bracket, match cut radius on top of bracket to cross member protruding from frame.
- If you are installing Piggy-Back Remote Reservoir Shocks there will be a Small Parking Brake Bracket included that will attach to the lower passenger side rear control arm as pictured to hold the brake cable off of the shock body.
- Remove the hold down on the axle and re-use the bolt for the new bracket.

2. Small Parking Brake Bracket (*image 2*)

- Remove Bolt holding the wire type cable guide from the upper control arm.
- Pry open the wire loop with a flat tip screw driver or pair of channel locks and discard
- Using the OEM bolt, install the Small Thuren Parking Brake Bracket as shown (*image 2*)
- Holding the parking brake cable in place, use a small flat tip screw driver and pry the metal tab retainer up into place.