



Strapping Kit Install Instructions for Transit 10 Gallon Water Tank (Passenger Side)

Tools Required:

- Rivet Gun
- 7/16" Metal Drill Bit
- 13mm Socket
- Permanent Marker
- Thread-Lock (Loctite)
- Anti-Rust Spray Paint



STEP 1: Temporarily bend back the heat shield.



STEP 2: Find placement of strapping for top riv-nuts using the center most 8mm factory studs.



STEP 3: Use an 11mm or 7/16" metal drill-bit to enlarge the hole to the correct size for the riv-nut (the Hex works well for the rear strapping).



STEP 4: Spray paint drill holes to seal the exposed metal.



Tip: Before installing the riv-nut I add Loctite to the contact point to avoid the t-nut spinning after installation.



STEP 5: Install Riv-nuts.



STEP 6: Install water tank and bend back the heat shield.