

stayflush

motorsports

SFM ProR / ProXp Switchpro Mount

Tools Needed

- **Philips screw driver or Drill**
- **T4 Hex head**

1. Sit the mount in place. Using a pencil, place a small mark to guide you on where to position the lower mounting bracket



2. Remove the console and using the self tap screw, screw in the bracket, not completely tight but enough to keep it in place and be able to adjust the height.



3. Position the mount back on the dash and adjust the bracket until it lets the console sit flush on the dash. Once it sits flush remove the console and tighten the lower bracket.



4. Place the mount back in place with switchpro mounted and 12v socket. Align the lower slot and tighten the M6 butt head bolt provided to the lower bracket installed on the previous step



5. Towards the rear of the mount you will find 2 holes. With the self tapping screws provided screw down the console tight.

