

sunbelly PRIVACY SCREENS

U-CHANNEL SET INSTALLATION INSTRUCTIONS

PACKAGE INCLUDES

- (2) Sunbelly U-Channels
- (2) Bottom locking blocks (2 holes)
- (2) Top locking blocks (1 hole)
- (14) Philips head screws (shorter)
- (6) Hex head screws (longer)
- (36) Spacers



TOOLS & MATERIALS

Drill and drill bits

Metal saw (hacksaw or other powered saw with an aluminum blade) - if changing height

Vertical posts and horizontal boards/slats*

Safety Gear - glasses, dust mask, gloves

INSTALLATION

1. Fasten the U-Channels to the posts through the pre-drilled holes with the 14 shorter screws.
2. Fasten the bottom locking blocks at the desired starting height for the horizontal boards/slats using 2 longer (hex-head) screws.
3. Add boards/slats, placing spacers between them by sliding spacers into front channel.
4. Once all boards/slats are in place, fasten the top locking blocks using 1 longer (hex-head) screw.

* U -Channel width can accommodate boards/slats up to 1" (25.4mm) thick.

If your boards/slats are less than 1" (25.4mm) thick, shims (not included) can be cut to help create a tighter fit.

INSTRUCTIONS D'INSTALLATION DE L'ENSEMBLE DE CANAUX EN U

LA BOITE COMPREND

- (2) Canaux en U Sunbelly
- (2) Blocs de verrouillage inférieurs (2 trous)
- (2) Blocs de verrouillage supérieurs (1 trou)
- (14) vis cruciformes (plus courtes)
- (6) Vis à tête hexagonale (plus longues)
- (36) Entretoises



OUTILS ET MATÉRIAUX

Perceuse et forets

Scie à métaux (scie à métaux ou autre scie électrique avec une lame en aluminium) - en cas de changement de hauteur

Poteaux verticaux et planches/lattes horizontales*

Équipement de sécurité - lunettes, masque anti-poussière, gants

INSTALLATION

1. Fixez les profilés en U aux poteaux à travers les trous pré-perçés avec les 14 vis plus courtes.
2. Fixez les blocs de verrouillage inférieurs à la hauteur de départ souhaitée pour les planches/lattes horizontales à l'aide de 2 vis plus longues (à tête hexagonale).
3. Ajoutez des planches/lattes, en plaçant des entretoises entre elles en glissant les entretoises dans le canal avant.
4. Une fois que toutes les planches/lattes sont en place, fixez les blocs de verrouillage supérieurs à l'aide d'une vis plus longue (à tête hexagonale).

* La largeur du canal en U peut accueillir des planches/lattes jusqu'à 1po (25.4 mm) d'épaisseur. Si vos planches/lattes ont moins de 1po (25.4 mm) d'épaisseur, des cales (non incluses) peuvent être coupées pour aider à créer un ajustement plus serré.