

- Layers shown in cross-section need to be compacted. 4.
- Geo-textile is to be used for stability and to prevent mixing between layers. 5.
- We recommend anchors on each corner of the grid, and throughout the perimeter. 6. Needed on sloped installations, mostly.
- Follow for updates to the instructions and recommendations on the website vodaland.ca 7.

driveways, parking, stone paver base, shed base,

