



**EMPIRE
OFFROAD**

4" FOG

Installation Instructions

!!! Disconnect battery before attempting any electrical work or installation!!!


Installation Guide:

1. Disconnect battery.
2. Remove old fog lights. Process varies by model so search online for a video for your particular year and bumper design.
3. Inspect vehicle wiring harness and connectors for any damage. Repair if needed.
4. Note which style mounting bracket your old fogs use. The standard is 4tab which is included. Some use 3 tab designs and some use 2 tab designs. Those brackets are available for purchase online.
5. Clip off the fog connector from the jeep and attach the new connector unless you purchased the adapter cable. Red is positive and black is negative.
6. Install the new fogs into the bumper and connect the power connector.
7. Reconnect battery and enjoy your new fogs!




RED - 12V POSITIVE
BLACK - 12V NEGATIVE

4 TAB



3 TAB



2 TAB

