

4" FOG WITH RED ACCENT AND TURNS

Installation Instructions

III Disconnect battery before attempting any electrical work or installation!!

Installation Guide:

- 1. Disconnect battery.
- 2. Remove old fog lights. Process varies by model so search online for a video for your particular year and bumper design.
- 3. Inspect vehicle wiring harness and connectors for any damage. Repair if needed.
- 4. Note which style mounting bracket your old fogs use. The standard is 4tab which is included. Some use 3 tab designs and some use 2 tab designs. Those brackets are available for purchase online.
- 5. Clip off the fog connector from the jeep and attach the new connector unless you purchased the adapter cable. Red is positive and black is negative.
- 6. Wire the blue wire (White halo with red accent) to either the 12V+ marker lights or a switch of your choice.
- 7. Wire the yellow wire (amber halo) to the turn signal 12V+ (NOTE: blue wire has to have power in order for the amber halo to be able to operate)
- 8. Install the new fogs into the bumper and connect the power connector.
- 9. Reconnect battery and enjoy your new fogs!

RED - FOG POSITIVE BLACK - FOG NEGATIVE BLUE - WHITE HALO W/RED YELLOW - AMBER HALO

