



EMPIRE OFFROAD

LUMA Series Headlights Installation Instructions

Product Specifications

Input Voltage 12-24 vdc

Max output

Low Beam 3000 lumens

High Beam 6000 lumens

!!! Disconnect battery before attempting any electrical work or installation!!!

Installation Guide:

1. Disconnect battery.
2. Remove Grille to access headlight mounting bolts.
3. Remove 3 headlight retainer bolts using 10mm Socket.
4. Remove old headlights and inspect vehicle wiring harness and connectors for any damage. Repair if needed.
5. Remove fog lights if installing combo kit.
6. Route RGB Harness from control box to each headlight. Also route to RGB fog lights if installing combo kit.
7. Plug in the headlight main connector and RGB connector to each headlight. Install using factory hardware.
8. Install fog lights and splice fog light power wires to factory harness using butt connectors. Connect RGB connectors.
9. Reconnect battery and test each function for correct operation.
10. Zip tie or tuck away your wiring - Be careful to not pinch any wires.
11. Reinstall Grill and your ready to enjoy your new LUMA Series headlights!

