



For all models other than Rubicon, a sway bar disconnect system is provided in the kit.

Assemble the non greasable pin to the bracket as shown.

For Rubicon models simply connect the new sway bar links using the metal sleeve provided in the sway bar kit.

Tools:  
17mm socket & ratchet or spanner.



Fit the sway bar disconnect park brackets to the chassis rails.

This may require a hole to be drilled on some models.

Tools:  
5/8" socket & ratchet or spanner.



Fit greasable sway bar link pin and nut to axle bracket. Fit the grease nipple and tighten with spanner.

Hold flat section on pin with 17mm open end spanner to prevent pin from spinning when tightening.

Tools:  
19mm socket & ratchet or spanner.  
17mm open end spanner  
8mm Spanner.



Install new sway bar linkage as shown.

Fit link to sway bar first and secure fasteners.

Fit link to bottom and secure with R clip provided with kit.

Tools:

19mm spanner

6mm Allen key