



*Installation Instructions for the
BackBone Cargo Carrier*

1. If previously installed, carefully remove the four (4) Cargo Carrier pre-drilled hole plugs from the BackBone
2. Install one round gasket around each of the bolts with the adhesive side (up) towards the Cargo Carrier. There should only be one gasket around each bolt.
3. Insert the 6" sleeve onto one of the ends of the carrier tubing that does not have a bolt.
4. Insert the other end of the 6" sleeve onto the other piece of the carrier tubing.
5. From the rear of the Jeep with the tailgate open, carefully place the Cargo Carrier on top of the BackBone so that the bolts go through the pre-drilled holes.
6. Use included kept nuts to attach and tighten Cargo Carrier.

CAUTION !!!!!!!!

DRIVING THE JEEP WITH A SOFT TOP AND THE JEEPS WINDOWS ROLLED DOWN WHILE THE CARGO CARRIER IS INSTALLED MAY CAUSE VIBRATIONS THAT CAN DAMAGE THE TINT ON THE SOFT TOP'S WINDOWS