

PPM-3427 Stem Top Shock Adapter

INSTALLATION INSTRUCTIONS PPM-3427 STEM TOP SHOCK ADAPTER

GENERAL NOTES:

- These instructions are also available on our website at www.polyperformance.com
 Check the website for any updated instructions and additional photos for
 reference.
- Loosely bolt all hardware in until all bolts have been started, then torque to spec.

INSTRUCTIONS

- 1) Unbolt the old shock from lower and upper shock mount
- Note: It's often easier to reinstall shocks with suspension hanging free as to not have to compress the shock manually. Jacking the vehicle up, taking the weight off the suspension will make installation easier.
- 3) Loosely bolt the PPM-3427 Stem top adapter to the shock using the 1/2" bolt and nylock bolt provided with the kit. Use a washer on both the bolt and nut.
- 4) Loosely bolt the stem top adapter and shock into the upper shock mount using the 5/8" nylock nut and washer.
- 5) Install shock into lower mount and install shock bolt(s)
- Torque the lower shock mount to your vehicles specification
- 7) Torque the upper 5/8" nylock to 100 ft-lbs
- 8) Torque the 1/2" bolt to 80 ft-lbs