



Warrior, Inc.
11100 SW Industrial Way
Tualatin, Oregon 97062
(503) 691-8915 Main
(503) 692-0364 Fax
(888) 220-6861 Toll Free
wp@warriorproducts.com

SUBJECT: P/N 1563 - 07+ JK License Plate Bracket (Side Mount) Installation Instructions

NOTE: This installation can be done without, but WP recommends that you use Jeep part #55397112AA filler plate. This plate covers the factory license plate opening in the Jeep. You can simply drill a small hole for the LED wiring to fit through, so the large hole is not exposed to the elements. You may also want to obtain some factory touch up paint to cover the holes drilled during installation.

Installation:

1. Begin by unscrewing your license plate.
2. Behind the plate is an access panel where you will need to unplug your wiring for the license plate light.
3. Remove the mounting screws holding the bracket on. There are screws behind the mounting surface of the plate, as well as under the top surface of the bumper. The bumper end screws can be very tricky to remove without removing the bumper, and you may need to do so.
4. Remove the taillight by removing the two inner screws and unplugging the harness. This gives you access to the backside of the body to assist in installation.
5. You should now have the factory license plate mount and driver's taillight removed.
6. If you're using the Jeep filler plate, now is the time to pop the plate into place. You can pre-drill the hole for the wires to route through, or drill it once it is on the vehicle. Be careful when drilling to not crack the plastic.
7. Set your new bracket into place and mark the 4 holes to be drilled for installation. Drill holes with a 3/8" drill bit. Finish the holes with some touch up paint to help prevent rusting.
8. You will find included in the kit some rubber edge trim. This goes along the curved edge of the top of your license plate bracket. It simply slides on, and you can trim the ends to fit using a razor blade or scissors.
9. If it is not already installed. Slide your LED light into place. The two small metal screws supplied screw in from the back side and into the plastic of the light. Feed the wire through the small hole on the mounting surface, then through the small hole in the top of the bracket. You can use a grommet in the 1/4" hole in the bracket for a cleaner looking installation.
10. Feed the light wire into the hole in your Jeep filler plate installed earlier, and bolt your bracket into place using the supplied 5/16" countersink bolts, washers, and locking nuts.
11. You can now proceed with wiring your LED light. On the new marker light, the black wire is ground, and white wire is positive. You will need to determine which wire on the JK is which. The easiest way is to test it with the light. If you get them reversed, the light will simply not work. You will not damage the Jeep or the light.
12. Once your marker light is wired and tested to be working, and your 4 bracket bolts are tightened, re-install your taillight.
13. Finish the install by sliding your license plate into place over the studs. Use the supplied small washers and acorn nuts to secure the license plate to the bracket. This will complete your installation.

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.