



# VERMONT NATURAL COATINGS® **BÖHME**

SWISS QUALITY  SINCE 1866

*Böhme has been manufacturing stains and coatings in Switzerland since 1866. Now these natural hybrid-oil stains and finishes are made in the USA and available throughout North America through a partnership with Vermont Natural Coatings. The Böhme line, for both interior and exterior applications, applies, penetrates and looks like a traditional oil. These coatings clean up with soap and water, are easy to use and maintain, and are still < 30g/L VOC.*



## EXTERIOR DECK STAIN **Terra Plus**

CLEAR		
BROWN	CEDAR MILL	BUTTERNUT
SILVER GRAY	SLATE GRAY	PURE NATURAL
WALNUT	WESTERN RED CEDAR	HARBOR GRAY
OIL TONE	PALISANDER	SMOKE
WEATHERED	WHITE WASH	HONEY TONE

### TWO INNOVATIVE COMPANIES with a Shared Mission



Vermont Natural Coatings' revolutionary technology and 150 years of Böhme experience combine to deliver the safest, highest quality coatings in the world.  
SWISS QUALITY MADE IN THE USA.

Terra Plus Exterior Deck Stain provides lasting protection against moisture, mold and mildew with a strong resistance to foot traffic. Terra Plus is for use on decking and exterior stairs and can be used on new or properly prepared decks.



**Vermont Natural Coatings, Inc**

[www.VermontNaturalCoatings.com](http://www.VermontNaturalCoatings.com)

[info@VermontNaturalCoatings.com](mailto:info@VermontNaturalCoatings.com)

(802) 472-8700 Find us on 

# VERMONT NATURAL COATINGS®

## BÖHME

### TERRA PLUS

Through an innovative manufacturing process, Böhme harnesses the strengths of natural oil finishes into a safe, premium waterbased product.

#### RECOMMENDED USES:

Ideal for all exterior wood decking and stairs.  
Can be used on new or pre-stained wood.



Available in Quart, Gallon,  
and Five Gallon

- Superior waterproofing protection and UV stabilization
- Strong resistance to foot traffic
- Lasting protection from moisture
- Easy maintenance
- Custom colors available upon request
- Clean up with soap and water



• Premium Exterior Stains & Finishes •

#### PREPARATION & APPLICATION



**SURFACE PREPARATION:** Surfaces must be clean, dry and free of any grease, glue or other contaminants prior to staining. For previously stained wood, sand surface lightly to help adhesion. If coating unfinished softwood, we recommend using **Suncare 900** as a pre-treatment. For all other unfinished woods, pre-treat with **Hydro-Oil Primer**.

#### APPLICATION:

Apply when no rain is expected for 24 hours. For pressure treated wood allow 3-6 months before application. Not suitable for subterranean or submerged wood.



1) Stir well prior to use.



2) Always test the finish on a sample piece of wood to confirm the desired appearance.



3) Apply with brush, paint pad, roller or spray.



4) Two coats are recommended on all sides of wood.



5) Apply evenly with the grain and always maintain a wet edge. If rolling, follow with brush or paint pad.



6) For best results apply in temperatures between 45°-80°F and relative humidity of 40%-60%. Do not apply when rain is expected within 24 hours.

7) Product will be ready for second coat after 4-6 hours; pre-treated wood will be ready after 12- 24 hours. One gallon will cover approximately 300-400 sq. ft. depending on porosity of wood.

#### TECHNICAL DATA

Color in Container	Refer to label
Clarity (Dry)	Semi-Transparent
Chemical Resistance	No visual defects
VOC	Coating: 30g/L (wet)
Flash Point	None
Freeze/Thaw Stability	Do not freeze
Pot Life	12 months from date of manufacture
Dry Time	4-6 hours
Clean Up	Soap and water
Odor	Neutral
Maximum Cure	One week
Coverage	300 -400 sq. ft. per gallon

Vermont Natural Coatings, Inc  
info@VermontNaturalCoatings.com  
(802) 472-8700 Find us on

For project ideas and testimonials visit: [www.vermontnaturalcoatings.com](http://www.vermontnaturalcoatings.com)