

Assembly Instructions For The Appalachian Arbor

Tools Needed:

7/16" Wrench or Socket
Power Screwdriver
Hammer

Parts List:

Arbor Side Panels (2)
Arbor Top Assembly (1)

Hardware:

1/4" x 4-3/4" Bolts (8)
1/4" x 2" Lag Screws (8)
Hurricane Stakes (4)
Allen Wrench (1)

- Step 1** Move all parts to the desired location. Lay the side panels down lengthwise with the front or back faceboards resting on the ground. (To prevent them from getting dirty lay the packing foam or some cardboard down first). Once assembled the arbor is reversible & can be turned as desired.
- Step 2** Take the top assembly & place at the top of the side panels. The side panel faceboards are angled at the top & have the angled braces attached. Match the numbers on the top of the side panels with the corresponding numbers on the top assembly to ensure you are assembling correctly. The arbor will only fit together correctly one way. Align the two predrilled holes in each corner of the top assembly with the threaded inserts in the top of the posts & the braces. Insert the eight 4-3/4" bolts & tighten with the Allen wrench. **(Do not fully tighten any bolts until all bolts are in place & partially threaded into the inserts).**
- Step 3** Now set the assembled arbor up & in place. (You will need some help for this). Find the two predrilled holes in the bottom of each post on the inside of the arbor. Pound the hurricane stakes into the ground until the holes in the stakes align with the predrilled holes in the posts. Fasten with two 2" lag screws at each post. Turn in with the wrench or socket to secure the arbor to the stakes.
- Step 4** If you ordered the Timberland Swing with your arbor hook the rings at the ends of the ropes onto the hooks inside the arbor top assembly. Both ropes on one side hook onto the same hook. Adjust the ropes as needed. Check the swing assembly instructions for instructions on adjusting the ropes.

