

Assembly Instructions For the Arched Arbor

Step 1: Lay the sides of the arbor on a level surface so the screws on the lattice work are facing inward.

Step 2: Bolt one of the arches to both of the side pieces.

Step 3: Flip over the arbor and bolt the other arch to the sides.

***** Be careful not to bind!*****

Note: This will not be sturdy until it is buried in the ground.

Step 4: Now set the arbor upright and put the 5 2x4 rafters onto the arches using the 3" screws.

Step 5: Measure the bottom of the arbor opening, making sure it is the same as the top opening.

Step 6. Now pound a stake at each leg using 2 1/2" screws and fasten to leg.



Tools Needed for Assembly

Hammer
Screwdriver
Tape Measure
7/16 Socket

Part List

Side Assembly (2)

Arches (2)

2X4 Rafters (5)

Stakes (4)

Hardware

1/4 3" Bolts (8)

1/4" Nuts (8)

1/4 x 1" Fender Washers (16)

3" Screws (10)

2 1/2" Screws (8)