

Assembly Instructions for A-Frames

Tools required for assembly:

Hammer for tapping lag bolts
7/16" Socket



Parts List For A-Frame

4 – 4 x 4 Legs
1 – 4 x 4 Top Bar
2 – 2 x 4 Braces (long)
2 – 2 x 6 Braces (short)
14 - 5/16" x 2 1/2" Lag Bolts

For your convenience, A-Frame Swing Stands ship partially assembled and pre-drilled for easy installation.

Step 1: Line up the pilot holes for the bottom cross braces and secure using included lag screws.

Step 2: Line up the pilot holes for the top braces and secure using included lag screws.



Bottom Brace connection shown



Top Brace connection shown

Checking (cracks in the wood) may occur with these products. This is a normal and natural occurrence in wood, and will not affect the structural integrity of the wood and this product.