

Assembly Instructions For The Hickory Arm Chair

Parts List:

Chair (1)
Right Arm (1)
Left Arm (1)

Hardware:

1/4" x 1-3/4" Bolts (4)
Allen Wrench (1)

- Step 1** Place the chair on a level surface.
- Step 2** Take a chair arm and two 1-3/4" bolts. Align the predrilled hole on the back of the arm with the threaded insert on the side of the chair back. Insert a bolt and turn into the insert with the allen wrench provided and tighten.
- Step 3** Now align the predrilled hole on the bottom of the arm brace with the threaded insert on the side of the chair seat. Insert a bolt and turn into the insert with the allen wrench and tighten. Fasten the other arm the same way.

