



**Required Tools:**

- Cordless Drill
- #2 Square drive bit

**Hardware:**

- (6) 1 1/4" Screws

**Parts:**

- A = (1) Footrest
- B = (1) Left Leg
- C = (1) Right Leg



**Step 1**

On a soft surface, lay the footrest (A) onto its left side, as shown. Position the left leg (B) into the corner of the footrest, turning the leg so the countersink holes face up and the leg is up against the side. Fasten with (3) 1 1/4" screws.



**Step 2**

Repeat Step 1 with the right leg (C) on the right side of the footrest.



**Step 3**

Your footrest is now complete.... enjoy!

*Thank you for purchasing from Wildridge.*