

# Assembly Instructions For The Poly New Hope Footstool

## Tools Needed:

Screwgun  
#2 Square Drive Bit

## Parts List:

Footstool Top (1)  
Front Leg Assembly (1)  
Back Leg Assembly (1)  
Brace (1)

## Hardware:

1/4" x 1-3/4" Bolts (4)  
1-1/2" Screws (4)  
Allen Wrench (1)

- Step 1** Lay the footstool top upside down on a clean surface.
- Step 2** Place the leg assemblies inside the frame of the top. Align the predrilled holes in the side of the frame with the threaded inserts in the top of the legs. Insert a 1-3/4" bolt through the frame & turn into the inserts. Repeat at all four legs and semi-tighten. **Do not fully tighten until Step 3 is completed.**
- Step 3** Put the brace between the leg assemblies. Center the brace with the predrilled holes in the leg assemblies & fasten with the 1-1/2" screws. Screws are self drilling & no holes are needed in ends of brace if properly aligned. Set the footstool upright on a level surface. Make sure all legs are straight & level then fully tighten all bolts with the Allen wrench.

