## Cedar Garden Chair Assembly Instructions

Diago rose	I through instruction	ne hoforo acco	mbling product	
Please lead	l through instructio	nis before asse	ilibiliig product. –	

### Tools Needed for Assembly:

Drill

Pliers and/or 7/16" wrench

Hammer for tapping bolts and screws

## Parts List:

1- Back Assembly

1- Seat Assembly

2- Arm & Leg Assemblies

2- Stabilizer Boards

8- 1/4" Hex Nuts

8- 2" Screws (for stabilizer boards)

2- 1/4 x 5 1/2" Hex Head Bolts (for back and seat joists)

4- 1/4 x 3" Hex Head Bolts (for legs)

2- 1/4 x 3" Carriage Bolts (for arms)

10-Large Washers (for arm and leg bolts)

4- Small Washers (for back and seat joists)

#### Extra Hardware for Sweetheart Chair only

1- Sweetheart Board

4- 1 3/4" Screws (for sweetheart board)

#### Extra Hardware for Highback Chair only

2-5" Boards

8- 1 3/4" Screws (for 5" boards)

Step 1. Lay out and identify them by comparing them with the drawings on the next page.

Step 2. Bolt the seat and back assemblies together with the  $5 \frac{1}{2}$ " bolts using small washers on each end of the bolts. (put one small washer on the bolt before sliding it through the back and seat then use the other small washer on the end, then add the  $\frac{1}{4}$ " nut.)

Step 3. Fasten the arm and leg assembles to the seat with the 3" bolts. Put a large washer on each end of the bolts. Put one large washer on the bolt. Then slide it through the leg from the outside and then through the seat. Add the other large washer then the  $\frac{1}{4}$ " nut and hand tighten. Fasten the arms to the back with the two 3" carriage (smooth head) bolts. Use a small washer under the  $\frac{1}{4}$ " nut only.

Step 4. Attach one stabilizer board to the front legs, and up against the bottom of the seat, with four short screws, turning it so the notches fit over the legs. Do the same with the other stabilizer board to the back of the back legs in the same manner.

Step 5. For the Royal Highback and American Sweetheart chairs only. Lay the chair on its back and attach the appropriate 5" wide boards to the back, and on the Highback, also to the front of the seat. Use the 1 5/8" screws provided. Keep the same space between the board and the next slat.

Step 6. Go back over your Garden Chair and tighten all the nuts with a 7/16" wrench or pliers.
\*It may periodically be necessary to tighten screws and ¼" nuts.

# Cedar Garden Chair Assembly Instructions

Note: Diagrams below show the American Classic Chair (WF3130)

