NAPPY INSERT ABSORBENCY GUIDE

INSERT TYPE SPEED OF ABSORBENCY CAPACITY RATING 00000 00 Microfibre 0000 000 **Bamboo Cotton** 0000 000 Bamboo 00000 Hemp

QUICK TIPS

- Inserts can take anywhere between 6-10 washes to reach their full absorbency
- When combining insert types to meet your bubba bear's individual absorbency needs - layer inserts from fastest absorbing on top (closest to babies bum) to slowest on the **bottom layers**
- When using microfibre inserts Never place inserts against babies skin. Always place them inside the nappy pocket to avoid skin irritation

