



Service First Yarm Arm with the 30' Delta Sectional

We recommend inserting screws into each of the 4 sections of the 30' Delta Sectional flagpole when matched with the Service First Yard Arm Kit. This will prevent the pole from twisting and creating rope tangle.

Instructions:



1. Using a 7/64 drill bit, drill a pilot hole through both flagpole tubes at each of the 4 overlapping sections.



3/8" Screw

2. Insert a 3/8" screw into the pilot hole and secure. Repeat to each of the 4 sections.



3. This hole and screw size are just a recommendation. Other sizes will work just as well.