

GUIDE TO REFINISHING YOUR CABINETS!

1

Clean!

Clean the surface of your cabinets using a TSP; this will get rid of anything stuck to them, like stubborn kitchen grease.

2

Sand!

Give the surface of your freshly-cleaned cabinets a quick scuff-sand (a light hand sand to remove any gloss); this will aid in the primer adhering to the surface! Don't forget to clean off the sanding dust with a tack cloth before moving on!

3

Prime!

Apply one coat of our INSL-X® Stix® Waterborne Bonding Primer. This is a high-bonding primer that will stick to *almost* anything; like vinyl, ceramic tile, PVC, most plastics and most glossy surfaces.

4

Paint!

Apply **TWO** coats of our Advance® Waterborne Interior Alkyd paint. Advance® has excellent flow and self-levelling, and thus has a re-coat time of 16 hours. Advance® can be sprayed, rolled AND brushed.

5

Admire!

Sit back and enjoy your hard work!

Bonus Tip!

You can use this exact same process to refinish furniture in your space, too!

