



STEP BY STEP INSTALLATION INSTRUCTIONS

## Upper & Lower Door Bags

**Polaris RZR XP Turbo/Turbo S/XP 1000  
S 900 Factory Front Doors**

Upper Door Bags

**Part #3001008**

Lower Door Bags

**Part #3001009**

Visit our YouTube  
channel for detailed  
installation instructions





## Required Tools

- ¼" Ratchet
- T40 Torx
- T25 Torx
- Bolt hole alignment tool (punch, small screwdriver, etc.)
- Flat head screwdriver
- Thread adhesive (Loctite or similar)

## Install Time

Approximately 30 minutes

*Note: We recommend installing the lower door bags FIRST if you have both.*

## Lower Door Bag Installation

(Repeat the below steps for both lower doors)





### Upper Door Bag Installation (Repeat the below steps for both upper doors)





## Upper Door Bag Installation (Cont'd)

(Repeat the below steps for both upper doors)



*Installation of the Hypertech Powersports lower & upper door bags is complete. Now get out there and hit the trail!*

### Contact Info

Hypertech Tech Department

Phone: 901.382.8888

Fax: 901.373.5290

techsupport@hypertech.com

Office Hours: Monday-Friday, 8am-5pm Central Time

hypertech.com

### Hypertech

7375 Adrienne Place

Bartlett, Tennessee 38133

hypertech.com