

Tool Suggestions: - Chain Nose Pliers

- Side Cutters

Directions:

- 1. Cut a 4' piece of wire.
- 2. Starting a third of the way up the cuff, wrap your wire making 4-5 coils. Pinch the coils together to keep the coils close and tight.
- 3. Slide on a gemstone bead, lay and situate the gemstone on the flat cuff and wrap the wire around the cuff two times, while keeping the gemstone in place.
- 4. Repeat step 3 to the rest of your gemstones and coiling 2 times between each gemstone. Make sure to pinch your coils together to keep coils tight.
- 5. At the last coil, make 4-5 coils before cutting off excess.



DIY0000 - DIY Bracelet Cuff w/ Microfacet Garnet Designed by Kayla from DakotaStones

Components List

- (1) WR00044 24-Gauge Copper German Bead Wire
- (1) Z016187 Copper Plated Thin Square Flat Cuff Bracelet by Nunn Design
- (1) CHA4DC-F Chakra 4mm Diamond Cut Faceted Coin Bead Strand