



DIY0042 - DIY Beaded Fringe Earrings with Seed Beads - Turquoise/Black

Components List

- SB00106 - 8-91051-TB Galvanized Silver Miyuki Seed Beads Tube
- SB00066 - 8-9401 Black Opaque Miyuki Seed Beads Tube
- SB00076 - 8-9412 Opaque Turquoise Green Miyuki Seed Beads Tube
- A019679 - 3 Inch Silver Plated 20 Gauge Headpins
- Z017105 - 30mm Silver Plated Brass Hoop Frame
- TCZ0077 - Sterling Silver Earring Wire by Tierracast®

Tool Suggestions:

Chain Nose Pliers



Directions:

1. On a headpin, slide on the following beads and make a simple loop. Make TWO dangles of each set of beads:
 A: 12 black, 5 turquoise, 4 silver.
 B: 14 black, 5 turquoise, 5 silver.
 C: 16 black, 5 turquoise, 7 silver.
 D: 18 black, 5 turquoise, 8 silver.
2. On a headpin, slide on the following beads and make simple loop:
 silver, 20 black, 5 turquoise, and 9 silver.
3. Gently open your hoop and slide on the following sequence:
 A: 3 cream bead, 1.A dangle, cream bead, 1.B dangle, cream bead, 1.C dangle, cream bead, 1.D dangle, cream bead, and dangle from Step 2.
 B: cream bead, 1.D dangle, cream bead, 1.C dangle, cream bead, 1.B dangle, cream bead, 1.A dangle and 3 cream beads.
4. Slide hoop end back into its insert and using a flat nose, gently crimp the back insert down on the hoop end.
 (Note: you can use a small dot of glue for extra security.)
5. Open earwire loop and and slide on hoop and close loop.
6. Repeat all steps for other earring.