



DIY0128 - DIY Unisex Black Leather and Silver Anchor Clasp Bracelet

Tools Needed:

- Stainless Steel 6mm Rivet Setter by TierraCast - TC01812
- Any Leather Hole Punch Pliers - example TL00411

Recommended Tools:

- A014415 - 2.5x2.5 Inch Bench Block with Steel and Rubber
OR
A011605 - 2 1/2 Inch Small Bench Block

Components List

- (17) CH00949 - 10mm Black Imprinted Braid Leather
- (1) Z014863 - 20mm Rhodium Plated Round Hinged Bail Clasp
- (1) Z004142 - 32mm Imitation Rhodium Plated Adjustable Anchor Clasp
- (1) TC01677 - 6mm Silver Compression Rivet by TierraCast

Directions:

1. Use the 2.5mm leather punch to punch a hole 1/4 inch in from the end of the leather. Measure 1 3/4 inches from that hole, towards the center of the leather, and punch a second hole.
2. Repeat step one at the other end of the leather strip.
3. Fold one end of the leather around the loop of the clasp, pattern side out, and match up the holes. Put the rivet pin through the holes so that the bottom is on the inside of the bracelet next to the cut end of the leather. Gently push the rivet head onto the pin just enough so that it stays on.
4. Place the rivet on a hard surface, bottom down, and put the rivet setter over the head of the rivet. Hit the rivet setter with a hammer until the rivet is firmly in place.
**Note - If you are not using a bench block this will probably damage the hard surface so use a scrap of wood or something that you won't mind blemishes on.
5. Repeat this process on the other end of the leather but loop the leather around the hinged bail clasp. Once the rivet is set pinch the hinged bail and slide it through the outermost hole in the shackle clasp bar.