



DIY0142 DIY Gemstone and Czech Stud Ladder Earrings - Silver and Aqua Impression Jasper

Components List

Tool Needed:

- Two Chain Nose
- Round Nose Pliers
- Cutter

- (1) AQIM5X10DD-8 Aqua (Dyed) Impression Jasper Double Drill Rectangle 8-Inch
- (1) Y006544 - 12mm Two Hole Stud Antique Silver Czech Glass Beads
- (1) Z003183 - 2 Inch Silver Plated Brass Decorative Spear Headpins
- (1) A019631 - 2 Inch Silver Plated 20 Gauge Eyepins
- (1) Z016753 - 9mm Antique Silver Diamond Post Earring with Loop
- (1) SB00106 - 8-91051-TB Galvanized Silver Miyuki Seed Beads Tube
- (1) Z011515 - 5mm Silver Plated 18 Gauge Round Jump Rings - 25 Pack
- (1) A002814 - 10mm Silver Plated 18 Gauge Round Jump Rings - 25 Pack
- (2) TC01250 - Clear Rubber Earring Backs

Directions:

1. Using one of the Spear Headpins (Z003183) slide on 1 seed bead, 1 gemstone, 1 Czech stud bead, 1 gemstone, and seed bead.
2. Make a simple loop
3. Add another Spear Headpin to the other side. Add the seed bead first, slide the headpin through the 2nd hole in the gemstone and Czech stud bead, and another seed bead.
4. Make a simple loop

NOTE: to keep the spear part of the head pin facing out, you will need to make sure you make the loop on your headpin going from front to back.

5. You'll repeat the same process in steps 1-4 but using the eyepins (A019631). Making simple loops on both ends.

NOTE: make sure your loops are going to opposite directions. The ones you attach to the loops you made with the Spear headpins should be going side to side. The loops at the top should be going front to back.

6. Attach the two pieces together.
7. Slide one of the larger jump rings through the top 2 simple loops you made and close the jump ring.
8. Add the post earring to one of the smaller jump rings and slide that onto the big jump ring you added in step 7.
9. Repeat all steps for the other earring.