



## DIY0155 DIY Wide Shredded Leather Cuff with Chrysocolla Coin Cabochons

### Components List

- (1) Z011783 - Taco Shredded Leather Cuff
- (17) CAB-CHR4DC - Chrysocolla 4mm Coin Cabochon

#### Tool Needed:

- Tweezers or Jewel Setter (A011802)
- Loctite (Z007890)

#### Directions:

1. Unsnap the cuff and lay flat.
2. Start by marking where you want to add your cabochons with an ink pen. In this design Heidi measured out the spacing and added more markings as she went.
3. Start gluing your cabochons. The Loctite super glue is so easy to use, just a little drop and then position your cabochon where you want it.

•\*\* NOTE - Loctite does not dry immediately. The glue will fully cure in 12-24 hours. Do not wear until it's fully cured.

