



DIY0157 DIY Scallop Wood Frame with Natural Chinese Turquoise Cabochons Earrings
Components List

Tool Needed:

- Tweezers or Jewel Setter (A011802)
- Loctite (Z007890)
- Chain Nose Pliers

- (2) Z010545 - 82x60mm Jumbo Oval Scallop Cutout Cherry Wood Pendant
- (8) CAB-NCT5DC - Natural Chinese Turquoise 5mm Coin Cabochon
- (6) CAB-NCT7x5OV - Natural Chinese Turquoise 7x5mm Oval Cabochon
- (1) A001530 - 8mm Silver Plated 18 Gauge Round Jump Ring - 25 Pack
- (1) Z011500 - 4mm Silver Plated 20 Gauge Round Jump Ring - 25 Pack
- (1) Z003694 - 18mm Silver Plated Brass Elegant Hook Earrings

Directions:

1. Start by choosing which Cabochons you want to go where on your wood components.
 - I put one oval cabochon on each side of the wood components and then another oval cabochon at the bottom in the middle. Then I added the round ones in between the ovals.
2. The Loctite super glue is so easy to use, just a little drop and then position your cabochon where you want it. Continue doing this until you've achieved your desired design.
 - Loctite does not dry immediately. You want to wait a minimum of 5 minutes before moving on to step 3. The glue will fully cure in 12-24 hours.
3. Add 2 of the large jump rings to the hole on the wood component and close them.
4. Attach one small jump ring to both of the large jump rings and add your ear hook to that jump ring and close it.
5. Repeat all step for the other earring.