



Tool Needed:

- Chain Nose Pliers
- Round Nose Pliers
- Cutter

DIY0166 DIY Shoulder Sweeping Fringe Earrings

Components List

- (1) A001493 - 2 Inch Silver Plated 21 Gauge Headpins
- (1) A019631 - 2 Inch Silver Plated 20 Gauge Eyepins
- (1) SB00106 - 8-91051-TB Galvanized Silver Miyuki Seed Beads Tube
- (1) SB00073 - 8-9409 Opaque Chocolate Miyuki Seed Beads Tube
- (1) SB00114 - 8-92021 Matte Opaque Cream Miyuki Seed Beads Tube
- (1) SB01455 - 8-94514 Picasso Seafoam Green Matte Miyuki Seed Beads Tube
- (1) Z017105 - 30mm Silver Plated Brass Hoop Frame - 5 Pairs
- (1) CH01095 - 2.2mm Silver Plated Tiny Oval Chain
- (1) TCZ0077 - Sterling Silver Earring Wire by Tierracast®

Directions:

1. Building the earrings from the bottom up, you will start by making the bottom layer of fringe.

- Slide the seed beads on a head pin in the following order:

- 1 – silver bead
- 3 – chocolate brown beads
- 1 – green bead
- 1 – chocolate brown bead
- 1 – green bead
- 1 – chocolate brown bead
- 3 – green beads
- 1 – cream bead
- 1 – green bead
- 1 – cream bead
- 1 – green bead
- 3 – cream beads
- 1 – silver bead

- Trim the head pin and make a simple loop.
- Make 7 of these

2. Make the top layer of fringe.

- Slide the seed beads on an eye pin in the following order:

- 1 – silver bead
- 3 – cream beads
- 1 – silver bead
- 1 – green beads
- 1 – silver bead
- 1 – green beads
- 3 – silver beads

- Trim the eye pin and make a simple loop.
- Make 7 of these

3. Open the loop you made on the bottom fringe pieces and attach one of the top fringe pieces. You will have 7 fringes with a top and bottom.
4. Make the side fringe pieces
 - Slide the seed beads on a head pin in the following order:
 - 1 – silver bead
 - 3 – cream beads
 - 1 – silver bead
 - 1 – green beads
 - 1 – silver bead
 - 1 – green beads
 - 3 – silver beads
 - Trim the head pin and make a simple loop.
 - Make 2 of these
5. Cut the chain as follows:
 - 5 links – cut 2 pieces
 - 7 links – cut 2 pieces
 - 9 links – cut 2 pieces
 - 11 links – cut 2 pieces
 - 13 links – cut 1 piece
6. Attached the chain pieces with 5 links to the 2 side fringe pieces you made in step 4.
7. Attach the rest of the chain pieces onto the remaining fringe pieces.
8. Start adding everything to the silver hoop by gently pulling open the one side of the hoop
 - 3 - silver beads
 - 1 – chocolate brown bead
 - 1 – side fringe piece with 5 chain links
 - 1 – chocolate brown bead
 - 1 – fringe piece with 7 chain links
 - 1 – green bead
 - 1 – fringe piece with 9 chain links
 - 1 – green bead
 - 1 – fringe piece with 11 chain links
 - 1 – cream bead
 - 1 – fringe piece with 13 chain links
 - 1 – cream bead
 - 1 – fringe piece with 11 chain links
 - 1 – green bead
 - 1 – fringe piece with 9 chain links
 - 1 – green bead
 - 1 – fringe piece with 7 chain links
 - 1 – chocolate brown bead
 - 1 – side fringe piece with 5 chain links
 - 1 – chocolate brown bead
 - 3 - silver beads
9. Slide the end of the hoop back into it the tube and using your chain nose pliers (or flat nose pliers) gently crimp the tube down until it is secure. (Note: you can use a small dot of glue for extra security)
10. Open the loop on the TierraCast ear wire and attach to the loop on the hoop. Be sure to note the front and back of the hoop and make sure your ear wire is facing the correct way.
11. Repeat all the steps for the other earring.