



DIY0169 DIY Triple Layer Silver Necklace with Crazy Lace Agate Slice

Components List

Tools Needed:

- Chain Nose Pliers
- Cutter
- Loctite Glue (Z007890)
- Nylon Jaw Pliers (optional)

- (1) **PEN-CLA27-34SLC-SP** - Crazy Lace Agate 27x34mm Slice Silver Plated
- (1) **Z001940** - 10mm Sterling Silver Pinch Bail
- (2) **CH01221** - 1.25mm Stainless Steel Snake Beading Chain
- (2) **CH01222** - 3x6mm Silver Plated Kinked Paperclip Cable Chain
- (2) **CH01215** - Paperclip and Round Cable Chain Combo - Silver
- (1) **Y008570** - 2mm Silver Plated Brass Cord End Cap with Loop - 4 Pack
- (1) **A015902** - Silver 3 Strand Tube Clasp
- (1) **Z011515** - 5mm Silver Plated 18 Gauge Round Jump Rings - 25 Pack

Directions:

1. Trim the snake chain (CH01221) to desired length. For this project I used the full 2 feet.
2. Attach the cord end caps with loop to each end of the snake chain using the Loctite glue. Add a small drop to the end of the chain and gently insert into the end cap.
 - a. As per the Loctite instructions, hold the chain and end cap together for 15-30 seconds. Leave it undisturbed for at least 5 minutes. It will fully cure in 12-24 hours.
3. Attach the pinch bail to the gemstone pendant by gently pinching it together. Using a nylon jaw pliers are helpful so as to not mar the metal, but you can also use any pliers. Just be very gentle!
4. Trim the paperclip chain (CH01215) to the desired length. This project example is approximately 23" long.
5. Trim the kinked paperclip chain (CH01222) to the desired length. The project example is approximately 17" long.
6. Using the jump rings, start attaching the chain ends to the tube clasp in the desired positions.
7. Once the snake chain is ready to be handled (after 5 or more minutes after the glue has been applied to the end caps), slide the bail with gemstone onto the chain and attach the ends to the tube clasp with jump rings.