



## DIY0173 DIY Tourmaline and Gold Drop Charm Earrings

### Components List

#### Tools Needed:

- Two Chain Nose Pliers
- Round Nose Pliers
- Cutter

- (1) **Z001831** - 8mm Gold Plated Post Earrings
- (2) **Z004556** - 21mm Antique Gold Large Organic Hoop by Nunn Design
- (1) **Z021696** - 30mm Gold Plated Brass Circle with Bar Connector Charm - 4 Pack
- (2) **Y005913** - 18mm Gold Plated Star Burst Charm with Yellow Jade
- (1) **TML2CUB-F-A** - Multi Tourmaline 2mm Faceted Cube - 15-16 Inch
- (1) **Z011522** - 6mm Gold Plated 20 Gauge Round Jump Ring - 25 Pack
- (1) **AW00088** - 26 Gauge Gold Artistic Wire

#### Directions:

1. Wrap the 2mm Tourmaline around half circle and bar connector of Z021696 starting at the loop and working your way around wrapping twice in between beads for security. Trim the wire. Be sure to press down onto the tail of the wire so there are no sharp points stick out.
2. Using the jump ring attached to the starburst charm (Y005913), attach it to the loop on the part of the connector where you started the wire wrapping.
3. Using one of the 6mm round jump rings attach the organic hoop (Z004556) to the part of the connector that you did not wire wrap.
4. Using another 6mm round jump ring, attach the earring post to the organic hoop (Z004556).
5. Repeat all steps for the other earring.