



DIY0191 DIY Heavy Metal Earrings

Components List

- (1) **CH01140** - 7.25mm Bright Silver Triangle Chain
- (2) **A008118** - 2.2mm Silver Plated Ornate Chain
- (1) **Z001661** - 4mm Silver Plated Brass 24 Gauge Oval Jump Rings
- (1) **Z001829** - 8mm Silver Plated Post Earrings
- (1) **Z005314** - 24x33mm Rhodium Plated Arched Components - 1 Pair

Tools Needed:

- Chain Nose Pliers
- Cutter

Directions:

1. Start by cutting a piece of the triangle chain (CH01140) that has 11 triangles. Set that aside.
2. Then cut 2 pieces of the ornate chain (A008118) in pieces that are 10 links each. Ten links is 1 inch. If you customize this part, make sure the 2 pieces of chain measure exactly the same.
3. Cut off 1 triangle from the triangle chain.
4. Using the oval jump rings attach each piece of the ornate chain to both sides of the triangle.
5. Using 2 more jump rings, attach the ends of the chain to the inside loops of the arched component.
6. Now cut 2 pieces of the ornate chain (A008118) that are 22 links each. 22 links is 2.25". Again, if you want to customize and go with a different length, just make sure the 2 pieces measure exactly the same.
7. Cut off 1 triangle from the triangle chain.
8. Using the oval jump rings attach each piece of the 22 link ornate chain pieces to both sides of the triangle.
9. Using 2 more jump rings, attach this piece to the 2nd loops on both sides of the arched component.
10. Using 2 more jump rings, attach the triangle chain piece from step 1 to the outside loops on both sides.
11. The triangle chain piece should hang in front of the longer ornate piece that hangs from the 2nd loops.
12. Using a jump ring, attach the earring post to the top loop of the arched component.
13. Repeat all steps for the other earring.