



**Tools Needed:**  
- Two Chain Nose Pliers

## DIY0204 DIY Vintage Glam Antique Brass Earrings

### Components List

- (1) **Z020658** - 20x8mm Crystal Embellished Intricate Link/Connector in Antique Brass Plating from the Glam Collection - 2 Pack
- (1) **Z020621** - 25x15mm Crystal Embellished Ornate Drop Charm/Pendant in Antique Brass Plating from the Glam Collection - 2 Pack
- (1) **Z005285** - 25mm Crystal Embellished Kidney Ear Wires - Antique Brass Plated Brass from the Glam Collection
- (1) **Z009471** - 5mm Antique Gold Plated 18 Gauge Round Jump Rings - 25 Pack

### Directions:

1. Using a jump ring, attach the Link/Connector to the loop on the Drop Charm/Pendant and close the jump ring.
2. Feed the hooked part of the kidney earwire onto the other end of the Link/Connector.
  - a. We suggest pinching together the top part where the loop of the Link/Connector sits to secure it in place.
3. Repeat for the other earring.