

# *Soul*

## TS-MAYO-TRAY

- Step 1 : Insert Tray into inner vertical extension and secure with locking knob.
- Step 2 : Insert inner vertical extension into outer vertical support and secure with locking knob.
- Step 3 : Insert outer vertical support into base with coupler and gromet.

