

Document Name	Author	Owner	Version	Page
IFU Surg. ball hooks	Nils Kumar	Swadesh Kumar	2019_V2	1 of 1

Instruction for use for arch wire hooks/arch wire stops

1. Place the arch wire hooks on bonding tray with slot side facing the tape
2. Use Hook Crimping plier to lock the hook
3. Transfer to the arch wire in the mouth and press hard
4. Hook can be further secured with Hard Wire Cutter by crimping on the mesial and distal side of the hook.
5. If desired to bend the hook mesial or distal use Tweed Loop forming to bend the hook arm in the desired direction.