



HighLighter HeatShield Install Instructions:

What's Included: HS, 2 High Temperature Orings (1 large / 1 small), & Oring installation tool.

Step 1: Place the oring tool down into the upper cavity of the HS. With a pencil or pen make a small mark on the tool just under the rim. You will need to know this depth to roll the smaller Oring onto the glass joint. Push the wires through the smaller of the two orings then roll it onto the bottom of the glass joint. Place the tool on the glass joint with the mark at the top of the 18mm female. Roll the oring just up to the mark.



Step 2: Push the glass joint down into the HS through the dividing wall til the oring rests flat on the bottom. The glass may take a little force to push through the center hole but that's fine.

Step 3: Turn the HS upside down. Take the larger oring place over the wires then get it started on one side of the glass then hold it in place with your thumb. Use the flat end of the tool placing it just inside the oring then wrap the oring completely around the glass, that's the toughest part of the process. Once its around the glass using the flat end of the tool push the oring down and around the joint until it rests flat on the dividing wall.

Step 4: Push your wires through the bottom side hole then into your power jack.

That's it, you're ready to get lit!



Thank you for your purchase,

Ed