DECORATI M

Enjoy the new look of your windows. DECOZI window film series are self-adhesive film that recreates the look and feel of expensive privacy glass such as stained glass or frosted glass. DECOZI films provide complete privacy but still allows 70% light.

Our specially designed Do-lt-Yourself adhesive based window film makes installation easy. Most windows can be done in 30 minutes or less. Once properly installed, DECOZI window film guarantee up to 10 years.

BENIFITS OF DECOZI WINDOW FILM

- Provides complete privacy
- Blocks 99% Harmful UV ray
- Helps reduce fading to interior furnishings and floorings
- Wide selection of design patterns
- Applied to any types of clear residential/commercial windows



Concord, ON Canada

905-761-0131



Trouble with heat and glare? Install DECOZI Solar film series to block up to 80% of heat and

glare. Please ask your local DECOZI dealer for more detail

DECOZI Solar film products are only available by customer's request.









DECOZI DESIGN YOUR LIVING STYLE

DO IT YOURSELF **DECORATIVE FILM**

APPLICATION USES

- Glass door and sidelights
- Basement windows
- Washroom windows
- Shower doors (exterior application only)
- Window display in shops
- Office glazing partition
- Any windows that require privacy and design

INSTALLATION INSTRUCTION

Window film is applied using the wet method, which allows for easier installation. Milky white patches may occur in using the wet method, but these will disappear in approx. a week.



CLEAN THE WINDOW MAKING SURE TO REMOVE ALL DIRT, GREASE, ETC. Please DO NOT USE ammonia contained solutions(Windex) to clean. Use regular soapy water.

MEASURE THE HEIGHT AND WIDTH OF THE GLASS SURFACE. Allow approx. 1/2" extra material on each side of the film and cut the film to

LAY THE PRE-CUT DECORATIVE FILM ON A CLEAN FLAT SURFACE WITH THE RELEASE LINER UP OF

have someone hold the piece to be applied for you. Remove the liner, spraying the soapy water on the now exposed adhesive surface throughly, as the liner is removed.

APPLY A GENEROUS AMOUNT OF WATER TO THE GLASS. Cover the entire glass surface with enough soapy water. The soapy water prevents the film from sticking to the surface immediately, thereby allowing more time in which to properly position the film.

PLACE THE NOW WET FILM ONTO THE GLASS SURFACE. Spray a small amount of soapy water on the face of the film also. Remove the water and any air bubbles with the plastic squeegee working from the middle of the film to the outside edges.

IF ANY AIR BUBBLES OR WATER REMAINS, use the squeegee to smooth them out. Be careful not to push too hard and tear the film.

CUT OFF THE EXCESS FILM FROM THE EDGES OF THE WINDOW FRAME USING A SHARP KNIFE OR RAZOR AND A RULER. Place the ruler along the inside edge of the window frame where you need to trim, and cut between the ruler and the frame of the window. It is ideal to cut in one continuous movement.

USE THE PAPER TOWELS TO CLEAN UP ANY EXCESS WATER.



Remove any dirt or debris from the window



Measure window height/width and cut the film to 1/2" bigger size



Remove backing by using masking tape on both side of the film, spray soapy water on the glass and the film



Start squeegeeing from the center to press out air bubbles



Cut off the excess film from the edge of the window frame using snap-blade knife

TIPS

- ► The film may take a few days to dry in order for it to completely adhere to the glass.
- If you have bubbles that have not been worked out with the squeegee you may use a straight pin to pop the bubble and work the air out.
- ► Make sure there are no dry spots on the film prior to placing it on the glass.
- ► Take care when removing the release liner that the film does not roll over onto itself. It will stick together and is difficult to pull apart!
- If the weather is extremely cold outside and soapy water is freezing on the window, windshield washer fluid may be substituted.
- ▶ All of the films have a liner applied to the back of them. If you are having trouble removing the liner, apply a piece of tape on the front, and one on the back of one of the corners of the film. As you peel the two pieces of tape apart, the liner should peel away from the film along with the tape.
- ► Please DO NOT USE ammonia contained cleaning solutions (Windex) to clean the window.

