

ROOMblush

instructions



length: 1140 cm [4 strips of 285 cm]
width: 50 cm



Check before you open the rolls if the production date is with all the rolls the same!

1. Preparation / Make sure the wall surface is smooth, clean, dry and uniform in color. Hang up the wallpaper at ± 18 to 20 degrees.

2. Apply the glue directly on the wall / Use Perfax

3. The strips are numbered, please respect this order ▲ after you have cut them! We advise to number them.

4. Paste the first strip / Start at the top of the wall and cut the redundant material below on the skirting board. Wipe outwards with a wallpaper spatula to remove bubbles. Do not rub with hands or cloth, otherwise you damage the surface.

5. Paste the next strips / Same start. Strip 2 and 4 must be turned. Paste the strips very close against the neighbouring one.

7. Dry / Give your wall time to dry. Once it is dry, you will no longer see wet spots. Directly remove any glue spots with lukewarm water and a sponge (soft touching). Press the seams once with a roller.

In case of complaints, add the top of the label.

