

MAGLED-56-FS/-B Floor Stand Assembly Instructions



1. Slide the spring washer and small flat washer onto the bolt.



2. Slide the bolt up through the hole in the center bottom of the base.



3. Drop the raised washer over the bolt so that it fits neatly into the depression.



4. Drop the large flat washer and decorative spacer over the bolt.



5. Thread the bottom pole onto the bolt. Use the included wrench to tighten bolt head fully.



6. Thread the top pole into the bottom pole and tighten fully.



7. Insert the lamp assembly into the opening of the top pole. Secure into place using the wing bolt.

