

Brogue Moto KTM Turn Signal Installation Instructions

1. Remove your stock turn signals as required.

2. Install your new pin signal kit and adapter plate with the supplied washer and nut. **DO NOT PIN YOUR CONNECTOR UNTIL YOU HAVE INSTALLED YOUR NEW SIGNALS & ADAPTER PLATE ONTO THE BIKE.**

*With the correct tool, you can remove or unpin each connector if needed

3. Remove the blue weather seal from the connector & identify the wire placement (see pictures below).

4. Transfer the blue weather seal as shown & gently push the wire terminal into the back of the connector. Again, ensuring the correct orientation of the wiring (see photos below).

5. Listen for an audible click (confirms they are fully seated). Use a small tool to push on the back of the terminal if needed to fully seat each terminal into the connector.

6. Close out, connect & test to complete your installation. Install our resistor kit if needed (sold separately).

