

Brogue Moto Mirror Cap Installation Guide

1. Grease the O-ring area of the mirror cap. We recommend any type of white lithium grease (not included). **THIS IS A MUST!**



2. Lightly seat the mirror cap while applying firm pressure and turning the cap (keep in mind if you have a left- or right-hand threaded perch).



3. It may be necessary to lightly seat the plug with a RUBBER mallet. Apply any masking tape to the top of the plug to protect the finish and tap into place.



4. Repeat steps 2-3 if required.



Thank you for your business!