





6 x 3.5m POLYTUNNEL ASSEMBLY GUIDE











STEP4



Loosely assemble complete frame, before tightening all bolts in final position.

STEP5



- 1) Please carefully follow the assembly instructions.
- 2) 2-3 people are recommended for final assembly.
- 3) Attach the cover to the frame using the ties located on the inside cover, hot spot tape (not supplied) may also be used. The ground skirt can be buried and weighted or surface mounted and weighted. Care must be taken to ensure weighting applied (locally sourced) is adequate to cope with weather conditions.