

SPACELABS

Quick Reference Guide

Accessories for: Ultraview



SpO2			
Nellcor OxiSmart		OEM #	Reorder #
		015-0660-00	S403-010
		700-0030-00	E708-740
Nellcor OxiMax		OEM #	Reorder #
		DS-100A	S403-01P0
		700-0792-00	E710-74P0

ECG			
Leadwires		OEM #	Reorder #
		3 Leads Snap 700-0007-00	LLB3-90S0
		3 Leads Pinch 700-0006-00	LLB3-90P0
		5 Leads Snap 700-0007-08	LLB5-90S0
		5 Leads Pinch 700-0006-10	LLB5-90P0
Trunk		OEM #	Reorder #
		3 Leads 700-0008-08	TL-23960
		5 Leads 700-0008-06	TL-25960

NIBP			
	OEM #	Reorder #	
		F188050	
		BP12	
	714-0061-00	AS-15-150	

Temp			
	OEM #	Reorder #	
		DHP-D-20-N0	box of 20
		DSL-30-PHO	
	20700-4000-00	DSL-AS0	

Order Now at planitmars.com

877-897-9338