

# Tile Drain Install

1. Apply base ply to subfloor.
2. Mechanically attach drain flange to baseply with nails or screws.
3. Apply waterproofing membrane over drain flange and baseply.
4. Set optional "positive weep protector" or similar over drain opening.
5. Install drain grate to desired height.
6. Pour mortar bed to desired height.
7. Apply thin set and tile or desired finish topping.

