



1 Slide comp onto the front of the firearm.

2 Install two (**longer**) screws into the side of the pic rail. Make sure everything is tightened up and in place.

3 Snap pic rail provided into place (should be easy to snap in). Make sure comp is sitting flush on the firearm.

4 Install (**smaller**) screws into pic rail.

5 Install 4 (**smallest**) screws into smaller holes on the bottom of the pic rail (install one and then another on top of it).

**The compensator will work without installing the set screws*

INSTALLATION INSTRUCTIONS

Make sure everything is tightened up and in place.

Tools Needed: 3/32" Allen Wrench, 0.05" Allen Wrench.

- You will use the small 0.05" Allen key to install the four set screws into the pic rail
- You will use the 3/32" Allen key to install the longer side-clamping screws and the bottom pan head screws

IMPORTANT: If screws are not threading in easily, do not force. Replace with an extra screw provided in the bag. Nothing should be forced into place. If you are having any issues getting the comp to attach, please do not use and contact us for a replacement.

