

**TALLBOY**<sup>™</sup>  
De-Chlorinator & Sediment Filter

The ultra violet sterilizer will kill all living bacteria and microbes and ensure safe water for your family and plants.

**1**

To mount directly on top of the Tall Boy unit, remove all four top bracket screws, closest to the outer bracket edge. Position the clips at the front of the bracket, and replace two of the four screws to secure the clips. There's no need to replace all four screws, two will suffice.



Alternately, you can mount the 2 white clips onto a wall or flat surface within 12 inches of the Tall Boy unit. Then, snap the UV filter into the clips.



**2**

Attach the white RO line from your Tall Boy into one end of the UV filter. You will need to cut it to the length needed to make the bend into the UV filter. The other piece of white tubing can be attached to the other end of the UV filter and will be your final product line.

NOTE: Included UV lamp is rated for 12 months of continuous use. After that period a replacement of the lamp is necessary.

**3**

Zip-tie the ballast to the UV filter, connect the electrical line from ballast to UV unit, and then plug into a standard 110V wall plug. The UV filter does not have a particular direction the water must flow through so you can orient it in either direction. Extra tubing is available from your dealer or contact us.



**Included**

- UV Sterilizer w/ 3/8" QC Fittings
- UV Lamp - Rated For 12 Months
- 6 Watt Ballast
- Mounting Clips